



LED LIGHT MOUNTS - CHEVROLET EXPRESS

WARNING! READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION
CONFIRM MEASUREMENTS BEFORE DRILLING ANY HOLES

PARTS LIST:

INCLUDES

2 LED LIGHT MOUNTS (CE-WLPM)

TOOLS NEEDED:

DRILL W/ PHILIPS HEAD BIT
3/4" SOCKET/RATCHET
PHILLIPS HEAD SCREWDRIVER

INSTALLATION INSTRUCTIONS

DISASSEMBLY**STEP 1:**

With a drill and phillips bit, use self tapping screws to tighten hood bracket in place

**STEP 2:**

Remove 1/2" mounting bolts using a 3/4" socket

**STEP 3:**

Using a phillips head screwdriver, remove the screws from the plastic lining on windshield



DISASSEMBLY**STEP 4:**

Fit bracket into place and line up with bolts holes

**STEP 5:**

Thread screws back into holes on top of the bracket

**STEP 6:**

Tighten the screws into place using 3/4" socket



DISASSEMBLY**STEP 7:**

Replace screws into the plastic lining on the windshield using a phillips head screwdriver

You are now good to continue with wiring and mounting your LED lights

