



## REAR DOOR MOLLE PANEL - 1992-CURRENT FORD E-SERIES

**WARNING! READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION**  
**CONFIRM MEASUREMENTS BEFORE DRILLING ANY HOLES**

### PARTS LIST:

- 1** WTD — REAR DOOR MOLLE PANEL (FES-MP-PRD)
- 1** WTD- UPPER MOUNTING BRACKET
- 1** LOWER MOUNTING BRACKET
- 1** LOWER MOUNTING BRACKET INSERT
- 1** HARDWARE (FES-MP-RD-H)
  - 7** 1/4-20 X 3/4 CAP SCREW
  - 2** 1/4 WASHER
  - 2** 1/4-20 NYLOCK NUT

### TOOLS NEEDED:

- PHILIPS SCREW DRIVER
- DRILL
- 1/4 DRILL BIT
- RAZOR BLADE
- 1/4 ALLEN BIT
- BLUE PAINTERS TAPE
- SHARRPIE
- TAPE MEASURER

**INSTALLATION INSTRUCTIONS**

**INSTALLATION**

---

**STEP 1:**

With the drivers side door open, remove the door locking pin by unscrewing it

**STEP 2:**

Now remove the upper plastic portion by pulling it out of the metal clips

**STEP 3:**

Remove screws from lower panel as well as handle if van has one



**INSTALLATION****STEP 4:**

Now lift up on lower panel to remove it  
Be sure to disconnect the wiring as well

**STEP 5:**

Remove the speaker to gain access to the location of mounting bracket

**STEP 6:**

Center bracket on the door and drill  $\frac{1}{4}$  hole for hardware



## INSTALLATION

### STEP 7:

With holes drilled place mounting bracket over hole and insert threaded aluminum bracket under door sheet metal and start threading  $\frac{1}{4}$  -20 hardware into mounting plate.

*\*Note: Do not tighten these screws, just get them started in the holes*



### STEP 8:

Re-install speaker and wiring



### STEP 9:

Measure the lower mounting bracket and trim the top center lower plastic accordingly

9 3/8 = top left corner to the edge

15 3/4 = Top Center



## INSTALLATION

### STEP 10:

Be sure to get all clips in the door and slide panel down

With lower panel installed, now tighten ¼ allen bolts



### STEP 11:

When inserting the upper panel, trim the lower plastic to fit, and re-install again



### STEP 12:

Mount molle panel to lower mount using ¼-20 allen bolts



## INSTALLATION

### STEP 13:

Take upper mounting panel and align with molle panel to determine where it will be mounted

Using the 2 self tapping screws, drill through the plastic in the sheet metal of the door



### STEP 14:

Now use ¼-20 bolts to attach the molle panel to the upper mounting bracket and tighten

Congratulations! You've just installed the WTD Rear Door Molle Panel. Time to hang some goodies on it!

