



WHEEL HUB SPACER - CHEVROLET EXPRESS

WARNING! READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION
CONFIRM MEASUREMENTS BEFORE DRILLING ANY HOLES

PARTS LIST:

FRONT

1 CHEVROLET EXPRESS HUB SPACER KIT (CE-HS)

HARDWARE KIT (CE-HS-H)

4 M16-2.0X50 BOLT

8 14MM HEX FLANGE BOLT

4 WASHER

4 LOCK WASHER

TOOLS NEEDED:

N/A

INSTALLATION INSTRUCTIONS

DISASSEMBLY

STEP 1:

Line up the cutout of the Hub Spacer with the spindle.



STEP 2:

Insert one of the WTD supplied bolts through the spindle and hub spacer to keep it aligned.



STEP 3:

Install the sheet metal dust shield and hub into spindle and begin to thread it into the hub.

Repeat with 3 remaining bolts.

Torque to 133 ft lbs



DISASSEMBLY

STEP 4:

Using WTD supplied bolts, slide through spindle.

Now slide spacer on and align with brake caliper and begin threads.

Repeat with lower bolt

Torque to 80-100 ft lbs



STEP 5:

Refer back to Chevrolet Spindle Install Instructions to complete spindle installation